




Nikon

BAYONET TYPE COMPARTMENT CASE (MODEL FB5)



The compartment case accepts a Nikon F Standard, Nikon F Photomic-T, T_N and FT_N or Nikkormat camera and 4 interchangeable lenses of focal length 300mm or shorter (except Fisheye-NIKKOR), one of which is attached to the camera and the other three to the bayonet bases provided in the compartment case.

The lens is attached to the bayonet base in the same way as to the camera.

NIKKOR Auto 21mm f/4 is not attached to the bayonet base but to the camera.

When NIKKOR Auto 300mm f/4.5 or 200mm f/4 is stored, the other lenses which can be accepted will be limited to the following combinations. (Numerals indicate the number of lenses)

Combination of Lenses

Combination Lens	I	II	III	IV	V	VI
300mm f/4.5 180mm f/2.8 80—200mm f/4.5	① 1	② 1	③ 1	X	X	X
200mm f/4	X	X	X	① 1	② 1	X
135mm f/2.8 or f/3.5	X	X	X	① 1	X	
*A group lenses	① 2	② 1	X	?	3	4
**B group lenses	1	2	3			
Total	4					

[Note]

*A group lenses: NIKKOR Auto 35 mm f/1.4
NIKKOR Auto 85 mm f/1.8
NIKKOR Auto 105 mm f/4
NIKKOR Auto 105 mm f/2.5
Zoom NIKKOR Auto
43 mm—86 mm f/3.5
PC NIKKOR 35 mm f/2.8

**B group lenses: NIKKOR Auto 20 mm f/3.5
NIKKOR Auto 24 mm f/2.8
NIKKOR Auto 28 mm f/3.5 or f/2
NIKKOR Auto 35 mm f/2 or f/2.8
NIKKOR Auto 50 mm f/1.4 or f/2
NIKKOR Auto 55 mm f/1.2
Micro-NIKKOR-P Auto 55 mm f/3.5
PC-NIKKOR 35 mm f/3.5
GN Auto NIKKOR 45 mm f/2.8

X: Cannot be stored.

①: To be attached to the camera or to the bayonet base marked ①.

②: To be attached to the camera or to the bayonet base marked ② or ③.

No marking: Can be attached in any way.

This table shows the combinations of four lenses. For combinations of three lenses or less, please attach them to the camera and suitable bayonet bases, according to your lenses.


Nikon

NIPPON KOGAKU K. K. Tokyo, Japan



Printed in Japan

Nikon

バヨネット式 ガゼットケース (FB5)



フォトミックT、TNまたはFTNファインダーおよび雑品



このケースはふたが前面に開くので収納品の取扱いが容易です。
1台のカメラと4本の交換レンズが収納でき、ほかにフォトミックT、TN、FTNファインダー、フィルターおよび雑品が収納できます。

4本のレンズのうち1本はカメラボデーに、残り3本はバヨネットによって基板に確実に取り付けられます。

カメラはニコンF、ニコンFフォトミックT、TN、FTNおよびニコマートのいずれでも、ニッコールオート300mm F4.5以下の短いレンズ(ただし、魚眼レンズを除く)付きで収納できます。ニッコール21mm F4レンズはカメラに取り付けた状態で収納してください。

ニッコールオート300mm F4.5またはニッコールオート200mm F4レンズを収納する場合には他の収納可能なレンズおよび各々の収納場所は下表のように制約されます。

なおレンズの着脱方法はカメラのレンズ交換と同様です。

交換レンズ収納表 (表中の数字はレンズ本数)

収納法 レンズ	I	II	III	IV	V	VI
300mm F4.5 180mm F2.8 80~200mm F4.5	①	①	①	×	×	×
200mm F4	×	×	×	①	①	×
135mm F2.8 または F3.5	×	×	×	①	×	
* A群レンズ	②	①	×			4
**B群レンズ	1	2	3	2	3	
合 計	4					

[注]

- * A群レンズ
- ・ニッコールオート35mm F1.4
 - ・ニッコールオート85mm F1.8
 - ・ニッコールオート105mm F4
 - ・ニッコールオート105mm F2.5
 - ・ズームニッコールオート43~86mm F3.5
 - ・P C ニッコール35mm F2.8

- **B群レンズ
- ・ニッコールオート20mm F3.5
 - ・ニッコールオート24mm F2.8
 - ・ニッコールオート28mm F3.5, F2
 - ・ニッコールオート35mm F2, F2.8
 - ・ニッコールオート50mm F1.4, F2
 - ・ニッコールオート55mm F1.2
 - ・マイクロニッコールPオート55mm F3.5
 - ・P C ニッコール35mm F3.5
 - ・G N オートニッコール45mm F2.8

×印: 収納できません。

①印: カメラか、バヨネット①に取り付けてください。

②印: カメラか、バヨネット②または③に取り付けてください。

無印: カメラに取り付けても、バヨネット①, ②, ③いずれに取り付けても差し支えありません。

表は4本のレンズを収納する場合を示していますが、3本またはそれ以下の組合わせは更に自由に行なえます。その場合はお手持ちのレンズに応じてご使用ください。

Nikon 日本光学工業株式会社

本社 103 東京都中央区日本橋通1-7(日本橋西川ビル) 電話(東京 272) 大代表3311
大井製作所 140 東京都品川区西大井1丁目6番3号 電話(東京 773) 大代表1111