

Zeiss Ikon Cameras

Price List No. 25

in effect March 27, 1935

CONTAX AND SUPER NETTEL

Literature and Price Lists on request

Cat.
Page

18

BABY IKOMAT

With Novar Anastigmat F/4.5, Derval shutter, no case	21.00
With Carl Zeiss Tessar F/4.5, Compur shutter, no case	41.25
With Carl Zeiss Tessar F/3.5, Compur shutter, no case	48.50
Zeiss yellow filter Lx21 for Novar F/4.5	5.00
Zeiss yellow filter Lx24 for Tessars	5.00
Sunshade 21 for Novar F/4.5	2.00
Sunshade 24 for Tessars	2.00
Portrait lens for Novar F/4.5 (#995/11)	2.25
Zeiss Proxar Portrait lens 1x24 for Tessars	5.00
Leather carrying case	2.50
Brilliant slip-on finder	1.75

19

IKOMAT A

With Novar Anastigmat F/4.5, Telma shutter, no case	29.00
With Carl Zeiss Tessar F/4.5, Compur shutter, no case	48.00
With Carl Zeiss Tessar F/3.5 Compur shutter, no case	55.00
Zeiss yellow filter Lx27 for Novar or Tessar F/4.5	5.00
Zeiss yellow filter Lx32 for Tessar F/3.5	6.00
Sunshade 27 for Novar	2.00
Sunshade 27 for Tessar F/4.5	2.00
Sunshade 32 for Tessar F/3.5	2.00
Portrait lens for Novar F/4.5 (#995/16)	2.25
Zeiss Proxar Portrait lens 1x27 for Tessar F/4.5	5.00
Zeiss Proxar Portrait lens 1x32 for Tessar F/3.5	6.00
Leather carrying case	3.25
Brilliant slip-on finder	1.75

20

IKOMAT C AND D

	C	D
With Novar Anastigmat F/6.3, no case	\$19.75	23.00
Leather carrying case	3.75	4.50
Zeiss yellow filter Lx25.5	5.00	
Sunshade 25.5	2.00	
Zeiss yellow filter Lx37		6.00
Sunshade 37		2.25
Portrait lens (#995/8)	2.25	
Portrait lens (#995/27)		3.00

IKOMAT C AND D SPECIAL

	C	D
With Carl Zeiss Tessar F/4.5, no case.....	\$47.50	\$56.00
Zeiss yellow filter Lx32.....	6.00	
Zeiss yellow filter Lx37.....		6.00
Sunshade 32	2.00	
Sunshade 37		2.25
Zeiss Proxar Portrait lens 1x32	6.00	
Zeiss Proxar Portrait lens 0.5 x 37.....		6.00
Leather carrying case	3.75	4.50

SUPER IKOMAT

**see special folder*

	A	C	D
With Carl Zeiss Tessar A F/3.5, and C & D F/4.5, no case	85.00	80.00	90.00
Zeiss yellow filter A Lx32, C & D Lx37	6.00	6.00	6.00
Sunshade A 32, C & D 37	2.00	2.25	2.25
Portrait lens A No. 995/17 for 23"...	3.00		
Portrait lens C No. 995/24 for 30" & No. 995/25 for 20"		3.00	
Portrait lens D No. 995/27 for 38" & No. 995/23 for 26"			3.00
Eveready leather carrying case	6.50	6.75	6.75
Leather carrying case	3.25	4.50	4.50
Soft leather pouch	3.25	4.00	4.00

SUPER NETTEL

**see special folder*

With Carl Zeiss Tessar F/3.5, no case.....	102.00
With Carl Zeiss Tessar F/2.8, no case.....	110.00
Eveready carrying case	8.00
Soft leather pouch	3.50
Zeiss-Ikon yellow filter	3.75
Zeiss Ikon ultra violet filter #975/1	4.50
Supplementary lens	3.00
Collapsible sunshade #1283/6	5.40

27

ICARETTE L

With Carl Zeiss Tessar F/4.5, in case.....	84.00
Zeiss yellow filter Lx32.....	6.00
Sunshade 32	2.00
Zeiss Distar 2.5x32 or 3x32	6.00
Zeiss Proxar 1x32 or 2x32	6.00
Film pack adapter	3.30
Plate holder	.80
Color plate holder	2.50
Ground glass back	3.75

28

NIXE A AND B

	A	B
With Carl Zeiss Tessar F/4.5, in case.....	95.00	106.00
Zeiss yellow filter Lx42.....	6.00	6.00
Sunshade 42	2.40	2.40
Zeiss Distar 2x42 or 3x42	6.00	6.00
Zeiss Proxar 1x42 or 2x42	6.00	6.00
Film pack adapter	3.75	
Plate holder	1.00	1.25
Color plate holder	2.75	
Ground glass back	5.00	5.50

MAXIMAR A AND B

A

B

With Carl Zeiss Tessar F/4.5, F.P.A., 3 P.H., no case	\$56.00	\$65.00
Zeiss yellow filter Lx32	6.00	
Zeiss yellow filter Lx42		6.00
Sunshade 32	2.00	
Sunshade 42		2.40
Zeiss Distar 2.5x32 or 3x32	6.00	
Zeiss Distar 2x42 or 3x42		6.00
Zeiss Proxar 1x32 or 2x32	6.00	
Zeiss Proxar 1x42 or 2x42		6.00
Film pack adapter	3.30	3.75
Plate holder	.80	1.00
Color plate holder	2.50	2.75
Ground glass back	3.75	5.00
Leather carrying case	5.50	5.50

IDEAL A

With Carl Zeiss Tessar F/4.5, 4 $\frac{3}{4}$ ", F.P.A., 3 P.H., in case	\$85.00
Zeiss yellow filter Lx32	6.00
Sunshade 32	2.00
Zeiss Distar 2.5x32 or 3x32	6.00
Zeiss Proxar 1.5x32 or 2x32	6.00
Film pack adapter	3.75
Plate holder	1.00
Color plate holder	2.50
Ground glass back	5.00

IDEAL B

With Carl Zeiss Tessar F/4.5, 5 $\frac{1}{4}$ ", F.P.A., 3 P.H., in case	100.00
With Carl Zeiss Tessar F/4.5, 6", F.P.A., 3 P.H. in case	108.00
Zeiss yellow filter Lx42	6.00
Sunshade 42	2.40
Zeiss Distar 2x42 or 3x42	6.00
Zeiss Proxar 2x42	6.00
Film pack adapter	4.50
Plate holder	1.25
Color plate holder	2.75
Ground glass back	5.50

UNIVERSAL JUWEL A

With Carl Zeiss Tessar F/4.5, 6" focus, F.P.A., 6 P.H. in case	299.00
With Carl Zeiss Tessar F/4.5, 6 $\frac{1}{2}$ " focus, F.P.A., 6 P.H. in case	313.00
Zeiss W.A. Protar 3 $\frac{3}{8}$ " focus with adapter for 6 or 6 $\frac{1}{2}$ " lens, compur shutter	42.00
Zeiss-Goerz W. A. Dagor 3" focus with adapter for 6" or 6 $\frac{1}{2}$ " lens, compur shutter	52.50
Zeiss yellow filter Lx42 for 6" lens	6.00
Zeiss yellow filter Lx51 for 6 $\frac{1}{2}$ " lens	7.50
Sunshade 42 for 6" lens	2.40
Sunshade 51 for 6 $\frac{1}{2}$ " lens	3.25
Zeiss Distar 2x42, 3x42 or 3.5x42 for 6" lens	6.00
Zeiss Distar 1.5x51, 2.5x51 or 3x51 for 6 $\frac{1}{2}$ " lens	7.50
Zeiss Proxar 2x42 for 6" lens	6.00
Zeiss Proxar 1.5x51 for 6 $\frac{1}{2}$ " lens	7.50
Film pack adapter	4.50
Plate holder	1.25
Color plate holder	2.75
Ground glass back	5.50

UNIVERSAL JUWEL B

With Carl Zeiss Tessar F/4.5, no F.P.A., 3 P.H., in case	\$434.00
Zeiss yellow filter Lx57	11.50
Sunshade 57	3.50
Zeiss Distar 1.5x57, 2x57 or 2.5x57	11.50
Zeiss Proxar 0.5x57 or 1x57	11.50
Double wooden plate holder	16.00
Extra lens board	2.50
Ground glass back	12.50

36

MIROFLEX A

With Carl Zeiss Tessar F/4.5, F.P.A., 6 P.H., in case	224.00
With Carl Zeiss Tessar F/3.5, F.P.A., 6 P.H., in case	242.00
With Carl Zeiss Biotessar F/2.8, F.P.A., 6 P.H., in case	321.00
Zeiss yellow filter Lx32 for F/4.5 lens	6.00
Zeiss yellow filter Lx51 for F/3.5 lens	7.50
Zeiss yellow filter Lx57 for F/2.8 lens	11.50
Sunshade 32 for F/4.5 lens	2.00
Sunshade 51 for F/3.5 lens	3.25
Sunshade 57 for F/2.8 lens	3.50
Film pack adapter	3.30
Plate holder	.80
Color plate holder	2.50
Ground glass back	3.75
Cable release for Miroflex	1.00

36

MIROFLEX B

With Carl Zeiss Tessar F/4.5, F.P.A., 6 P.H., in case	242.00
With Carl Zeiss Tessar F/3.5, F.P.A., 6 P.H., in case	315.00
With Carl Zeiss Tessar F/2.7, F.P.A., 6 P.H., in case	325.00
Zeiss yellow filter Lx42 for F/4.5 lens	6.00
Zeiss yellow filter Lx57 for F/3.5 lens	11.50
Zeiss yellow filter Lx69 for F/2.7 lens	27.00
Sunshade 42 for F/4.5 lens	2.40
Sunshade 57 for F/3.5 lens	3.50
Sunshade 69 for F/2.7 lens	5.00
Film pack adapter	3.75
Plate holder	1.00
Color plate holder	2.75
Ground glass back	5.00
Cable release for Miroflex	1.00
Lens board	9.00

IKOFLEX

**see special folder*

With Novar F/4.5	36.00
Zeiss yellow filter 24	5.00
Sunshade 24	2.00
Portrait lens set 3 to 1½ feet	6.00
Eveready carrying case	10.00
Leather carrying case	7.50

When ordering Distars, Proxars, Filters, Sunshades or Flanges.
specify whether for shutter with or without self-timer.

CONTAX

Special Price List for Contax and Accessories on request.

42

MIRAPHOT

With Novar Anastigmat F/6.3 including bulb.....	\$55.00
With Carl Zeiss Tessar F/4.5 including bulb.....	65.00
Miraphot bulb, 60 Watt 110 Volt (75 W. 125 V.)....	1.85
Negative carrier 45x107mm, 6x13cm, 9x12cm, or 10x15cm	1.85
Kits for 4½x6 cm, 6½x9 cm, or 3¼"x4¼" in 9x12 cm	.35

43

BABY MIRAPHOT

With Novar Anastigmat F/4.5, including bulb	47.00
Opal bulb 60 Watt 110 Volt (75 W. 125 V.)	1.45

45

HELINOX

Including bulb	10.00
Frosted bulb 40 Watt 110 Volt (50 W. 125 V.)	.80

46

MIRAX

With adapter for 2¼x3¼" cameras, including bulb...	17.50
Half frosted bulb, 60 Watt 110 Volt (75 W. 125 V.)	1.85
Negative carrier 9x12 cm	1.25
Kits for 4½x6 cm. or 6½x9cm. in 9x12 cm.	.35
Adapter for 2¼x3¼" cameras	1.50

47

MAGNIPHOT

Magniphot Enlarger, without lens	42.00
Magniphot Enlarger, with Special Anastigmat.....	56.50
Red Filter Attachment	5.40
Opal bulb 60 Watt 110 Volt (75 W. 125 V.)	1.45

EXPOSURE METER

Diaphot Exposure Meter	2.25
Helios Photo-electric Exposure Meter	27.75

48

TRIPODS

Metal Tripod	discontinued
Wooden Tripod	9.00

KINAMO S.10

With Carl Zeiss Tessar F/2.7	\$93.50
Supplementary lens (1 to 2 feet)	2.75
Supplementary lens (2 to 5 feet)	2.75
Yellow filter 2x	2.75
Carrying case for Kinamo alone	5.50
Carrying case for Kinamo with three films and all accessories	8.25
Eastman panchromatic film (in magazine)	2.50
Eastman super-sensitive panchromatic film (in mag.)	3.00

49

UNIVERSAL KINAMO

With Carl Zeiss Tessar F/2.7, 40 mm (with tripod and Panoram head)	182.00
Extra film magazine	4.25
Spring motor attachment with self-timing release ...	75.00
Spring motor attachment without time release	65.00

MICROPHOT

Microscope attachment Microphot with screen diaphragm	49.00
Extra screen diaphragm	2.50
Adapter for Cine-Kodak, Kinamo or Filmo 70 and Victor	9.00
Small adjustable stand for Cine-Kodak, or Filmo 70 and Victor	11.00

MISCELLANEOUS

Slide for plate holder or film pack adapter	.35
Plate holder or F.P.A. kit $3\frac{1}{4} \times 4\frac{1}{4}$ " in 9x12 cm.	.35
Plate holder kit $3\frac{1}{4} \times 5\frac{1}{2}$ " in 10x15 cm.	.45
Cable Release for compur shutter	.45
Spirit Level	.60
Infinity Scale for Distar or Proxar	.60
Focusing Scale	.60
Strap for carrying case	.60
Printing frame with glass 9x12 cm.	.60
Printing frame with glass 10x15 cm.	1.00
Transposing Stereo Printing Frame A, 45x107 mm. ...	3.75
Transposing Stereo Printing Frame B, 6x13 cm.	4.25
Stereoscope Model A, 45x107 mm.	14.00
Stereoscope Model B, 6x13 cm.	18.50

PAPER HOLDERS

(Hold enlarging paper flat and give clear-cut border)

Paper Holder for 6.5x 9 cm. ($2\frac{1}{4} \times 3\frac{1}{4}$ ")	1.20
Paper Holder for 9 x12 cm. ($3\frac{1}{2} \times 4\frac{3}{4}$ ")	1.20
Paper Holder for 10 x15 cm. (4 x 6")	1.50
Paper Holder for 13 x18 cm. (5 x 7")	1.50
Paper Holder for 18 x24 cm. (7 x $9\frac{1}{2}$ ")	1.50
Paper Holder for 24 x30 cm. ($9\frac{1}{2} \times 12$ ")	2.10

Zeiss Photo Lenses,—catalog on request.

Zeiss Distar, Proxar, Yellow and Ducar Filters,

Sunshades, see Camera model.

Zeiss Prism Binoculars,—booklet on request.