

Nikon

ACCESSORIES



VIEWFINDERS

FLASH UNIT

LENS HOODS

CASES




Model I • CLOSE-UP DEVICE for Nikon Camera. Fitted with 50mm f:2 Nikkor Lens. Permits photography at very close range, from 1.5 feet to 2.6 feet, coupled with the built-in range finder of the Nikon. Complete with leather case.

Model II • CLOSE-UP DEVICE. Same as Model I, but for 50mm f:1.4 Nikkor lens.



LENS HOOD, Model I for f:2 50mm Nikkor lens. Precision made, screw-in type, all metal construction. Accepts series six filters. Leather case supplied.


LENS HOOD, Model II. Same as Model I, but for 50mm f:1.4 lens and series seven filters.



SPORTS FINDER. All metal open frame finder for use with 35mm, 50mm, 85mm and 135mm lenses. Individual frames hinge up into position and entire unit folds down compactly to fit into leather carrying case (supplied with finder).



VARIFOCAL VIEW FINDER. "Zoom" type finder that magnifies image in proportion to focal length of lens for which it is set. Compensates for parallax. For use with 35mm to 135mm lenses. Available for Nikon or Leica. Leather case supplied.



INDIVIDUAL VIEW FINDERS. For wide angle 35mm, telephoto 85mm, telephoto 135mm lenses. Optical type, with provision for parallax correction. Leather cases supplied.



NIKON FLASH UNIT, Model BCB II. Operates on batteries alone or with battery-capacitor unit. Supplied with both small and large bulb reflectors, and battery-capacitor unit. Has built-in circuit testers, bulb ejector, multiple flash outlets, and many other new features.



FITTED LEATHER CARRYING CASE (Model I). Pre-formed rigid construction, with provision for Nikon Camera, Nikkor accessory lenses, lens hood, filters and exposure meter. Lock and adjustable padded shoulder strap that can be taken up to use as carrying handle. Beautifully lined.



SOFT LEATHER FITTED GADGET BAG (Model II). Metal inner liner to preserve shape of bag; cloth covered to protect equipment. Compartmented for Nikon Camera, Nikkor accessory lenses, view finders, lens hoods, filters, exposure meter. Soft leather outer pouch for films, bulbs, etc. Adjustable leather shoulder strap with shoulder pad. Zipper closure, with lock.

OTHER ACCESSORIES

- Connecting cord for flash unit
- Film cassette
- Every-ready leather case for Nikon Camera
- Leather cases for Nikkor accessory lenses
- Lens hoods for Nikkor telephoto lenses

Nikon Cameras and Nikkor Lenses are made by Nippon Kogaku, Tokyo, Japan.