

MALLORY

DURACELL® Photo Battery Guide



DURACELL®

The Photo Power Cell

DURACELL® The leading brand name in Alkaline Batteries — the Batteries that outperform regular batteries three, four — as much as five-to-one.

DURACELL® The dominant original equipment brand in the photographic industry — supplied in more photographic products than any other brand.

DURACELL Developed the Alkaline Battery System — recommended today by most photographic equipment manufacturers for best performance.

DURACELL Developed the first “AAA” & “BUTTON” cells for instamatic cameras...and the “9 VOLT” Alkaline Battery System — growing in importance for photographic use.

DURACELL Leader in advanced battery designs and technology — revolutionizing photographic equipment designs first with the “K” size battery, now with the new FLAT-PAK® Battery.

DURACELL®...No regular battery looks like it or lasts like it.

Index

Still Cameras Page 1
Movie Cameras Page 5
CdS Exposure Meters Page 9

Slide Viewers Page 11
Flash Units Page 13

Still Cameras

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
AGFA			
	Paxette-Iso Rapid F	1	PX23
	Selecta-M	2	MN1500
	Isomat	1	PX23
	Iso-Pak C and C1	2	PX825
	Optima 500 Sensor	1	PX13
	Agfomatic 126	2	PX825
	Selectronic	2	PX13
	Selectronic S	2	PX13
	1039, 1144/1145, 1177/1178, 1018	1	PX675
	C40	1	7R31
ALPA			
	SLR, IIel, IIe	1	PX28
	10d SLR	2	PX450
	9d SLR	2	PX625
ARGUS			
	75	2	MN1500
	Model 144 Skylark	2	MN2400
	Models 257, 260, 264 Insta-Load	2	MN9100
	Model 270 Insta-Load	1	PX13
	163, 164 and 284	2	PX825
	Models 166, 364, 374 Insta-Load	2	PX825
	1015, 1016, 1017, 1036 and 1037	1	PX675
	Cosina STL Reflex	1	PX675
	Model 235X, 345X Insta-Load	1	MN2400
	Model 355X Electronic	2	PX640
	Cosina 1038, 1039	1	PX675
	C-40	1	7R31
ASAHI-PENTAX			
	SP	1	RM400R
	6 X 7	1	PX28
	ES	1	PX28
	Data Camera	4	MS76
	Data Camera II	1	PX28
	ES II	4	MS76
	SPF	1	PX625
	SL	1	PX625
BELL & HOWELL			
	127 Electric Eye Model 901	1	M504
	Autoload 340, 341	{1 2	PX13 MN9100
	Autoload 342	2	MN2400
	35/2.8 Camera	2	MN2400
	Auto Reflex Dial 35 Camera	1	PX13
	FD 35	1	PX625
BESELER			
	Topcon Super D	1	PX13
	Topcon Auto 100, D1	1	PX13
	Topcon Unirex	1	PX13
	Super D Motor Drive	10	MN1500
BRONICA			
	EC	2	PX28
	S-2	2	PX625
	C-2	2	PX625
BRUMBERGER			
	Sabre 620	2	MN1500
	Valiant	2	MN1500
	Flash Flex 127	2	MN1500
CAMERA SPECIALTY			
	Amira Auto.	1	PX13
	Edixa LTL	1	PX13
	Edixa Electronic	5	PX1
	Terra	1	PX1
CANON			
	Dian 35	1	PX1
	FX	1	PX625
	Canonet S	1	PX1
	Canonet QL17	1	PX625

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
CANON (Continued)			
	Canonet QL19	1	PX625
	Pellix	1	PX625
	Pellix 7S	1	PX1
	Canonet QL25	1	PX625
	Dial Rapid	1	PX625
	Canonet QL19E	1	PX1
	Pellix QL	1	PX625
	Cano Matic C-30	2	MN9100
	Demi 17	1	PX625
	Dial 35-2	1	PX625
	Canonet 28	2	MN2400
	New Canonet QL17	1	PX625
	Cano Matic M70	2	MN2400
	FT-QL	1	PX625
	Canonet G-III 17	1	PX625
	Canonet G-III 19	1	PX625
	New Canonet QL19	1	PX625
	New Canonet 28	1	PX625
	Demi EE 17	2	PX625
	Canodate E	1	PX640
	Canodate E-N	1	PX640
	EX EE	1	PX625
	EX Auto	1	PX625
	FTb	1	PX625
	F 1	1	PX625
	EF	1	PX625
	Datamatic	2	PX640
	110-E	1	PX28
	110-ED	1	PX28
	TX	1	PX625
CONTINENTAL			
	Electroflash #555	2	MN1500
COPAL			
	Pocket 300	1	PX28
	Pocket 400	1	PX28
COSINA			
	Cosina Hi Lite EC	1	PX28
	Cosina 35	1	PX675
	Cosina Electro 35	1	PX28
DACORA			
	Rapid D101, D202, D404	1	PX13
	Instacora E and F	1	M504
	Instacora E2, R2, S2	1	PX23
EDIXA			
	LTL, 35MM	1	PX13
	Electronic, 35MM	1	PX1
EHRENREICH			
	Capromatic 250	2	MN2400
EXAKTA			
	VS1000, 500	1	PX1
FUJICA			
	V2	1	PX13
	Rapid SF	1	M504
	Compact Deluxe	1	MS76
	Compact D	1	MS76
	35FS	1	PX13
	35GP	1	PX13
	ST701	2	RM400R
	ST801	1	PX28
	ST901	1	PX28
	GE and GER	2	PX640
	GL 670 and 690	1	PX28
	Pocket 400	1	PX28
	Pocket 500 & 600	2	MS76

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
GAF CORPORATION			
GAF 76, Ansomatic 126, 136, 236, 326, 626		2	MN2400
Ansomatic 726		{2 1	MN2400 PX13
GAF 266, 266XF, Ansomatic 436		2	PX825
GAF 236XF, 266XF, GAF 200XF		1	PX825
GAF Autaset CdS		1	PX13
GAF Memo 35EE		1	PX675
GAF L-17, L-14, L-CS, L-CM		1	PX625
GAF L-ES		1	PX28
GAF 440, 660, 880 "K"		1	7R31
GAF BERNARD			
Ansomatic 126K, Viceroy 509, 126 camera, Viceroy 126K, Viceroy 126EE, Cadet 126EE		2	MN2400
Viceroy 500, Auto 35, Model 503		1	PX13
Viceroy 1000, Model 502		1	TR114R
GAF/LENCO			
Goldcrest 456EE, 126		2	MN2400
Goldcrest 126EE		2	MN1500
Goldcrest 126EE, Insta-Power		2	PX825
GRAFLEX			
Pacemaker Crown 45		2	MN1500
Speed Graphic 45		2	MN1500
Super Graphic 45		2	M215
HAMINEX			
Praktica LTL		1	PX13
Praktica Super LTL		1	PX13
Praktica LLC		1	PX21
Praktica PLC-2		1	PX21
Praktica VLC-2		1	PX21
Compact A 35mm		1	PX13
RF 35		1	7H34
ZF 35		1	7H34
WS w/flash		2	MN1500
		1	7R31
ES w/flash		2	MN1500
		1	7R31
PF428		1	7R31
HONEYWELL			
SP, SP500, SP1000		1	RM400R
SPII		1	RM400R
SPF		1	PX625
ES		1	PX28
ESII		4	MS76
IMPERIAL			
Lark		2	MN1500
Mark 27		2	MN1500
Cubex		2	MN2400
Delta		2	MN1500
Insta-Cube		2	MN2400
Insta-Flex		2	MN1500
Insta-Flash, Nos. 500, 501, 504		2	MN1500
Satellite		2	MN1500
900		2	MN2400
Deltex 127		2	MN1500
KALART VICTOR			
Kalart I & II		3	MN1400
KALIMAR			
Kalimatic "F," "MC"		2	MN2400
K-626 Diplomat		1	M504
K-650 2000 CTL		1	PX13
KEYSTONE			
Surveyor 55 Auto. Inst.		2	MN2400
125, 126, 128		2	MN2400
225, 226		2	MN2400
325		2	PX825
725		2	MN1500

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
KEYSTONE (Continued)			
K1010 Auto. Inst.		{2 1	MN2400 PX625
K1020 Auto. Inst.		2	MN9100
Signal Flash Inst.		2	MN2400
Everflash 10, 20, 40		2	MN1500
Pocket Everflash 120, 130		2	MN1500
60 Second Rapid Shoot 75		4	MN2400
60 Second Everflash 800		3	MN1500
Pocketmatic 404/30, 505/40		1	7R31
KODAK			
Pocket Instamatic 30, 40, 50, 60		1	7R31
Instamatic S-10, S-20, 714, 814		2	PX825
Brownie Fiesta R4		2	PX825
Instamatic 100, 104, 150, 154, 300, 304, 400, 404		2	MN2400
Instamatic 250, 324, 700, 704, 800, 804		2	MN9100
Automatic 35F, 35R4		2	MN9100
Motoromatic 35F, 35R4		2	MN9100
Retina 11 F		1	PX13
Instamatic 124, 134, 174, 314, 414		2	PX825
Instamatic X35, X45, X90		1	PX30
Instamatic Hawkeye A1		2	PX825
Instamatic Hawkeye F, R4		2	MN2400
Instamatic Reflex		2	PX825
Retina Si		1	PX23
Hawkeye Flashfun 1 & 2		2	MN1500
Instamatic X-30		1	7R31
Hawkeye Pocket Instamatic III		1	7R31
Trimlite Instamatic 28		1	7R31
Trimlite Instamatic 38		1	7R31
Trimlite Instamatic 48		1	7R31
EK4 Instant Camera		1	7K67
EK6 Instant Camera		2	7K67
KONICA			
Autoreflex N-T3, T3, T2, A3, A1000, A2, A, FTA		2	PX675
Auto-Reflex (External Exposure Meter) Autorex		1	PX13
Auto S-3		1	PX675
Auto S-2, Auto S-1.6		1	PX625
Auto-S, Auto-S261 (For Meter)		1	PX625
Auto S-E		1	RM1R
EE-Matic R (For Meter)		1	PX625
Electron		1	PX675
C35 Automatic, C35-V, C35-FD, C35		1	PX675
Konipak 100, 300, Sakurapak 100, 300		2	PX825
KOWA			
SE, SER, SET-R, SET-R2		1	PX625
Super 66, 6MM, 6 Meter/Finder, Meter/Prism		1	PX625
LEITZ			
Leica M2, M4 Motor		8	MN1500
Leica M5		1	PX625
Leicaflex		1	PX625
Leicaflex SL-2		2	PX625
Leicaflex SL		1	PX625
Leicaflex-SL Motor		10	MN1500
Leica CL		1	PX625
Leicaflex SL2 MOT		{10 2	MN1500 PX625
MAMIYA			
Sekor 500 DTL		1	MS76
Sekor 1000		1	MS76
Sekor 528 TL		1	MS76
Sekor Auto XTL		1	MS76
Sekor 1000 DTL		1	MS76

STILL CAMERAS (Continued)

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
MAMIYA (Continued)			
	Sekor 500 DTL	1	MS76
	C330 Professional	1	MS76
	220 Professional	1	MS76
	RB67 Professional	2	MS76
	M645	1	PX28
	MSX500	1	MS76
	MSX-1000	1	MS76
	DSX-500	1	MS76
	DSX-1000	1	MS76
	528AL	1	MS76
	AUTO-X 1000	1	MS76
MINOLTA			
Single Lens Reflex Cameras			
	XK	2	MS76
	XK Motor	2	MS76
	XE-5	{10 2	MN1500 MS76
	XE-7	2	MS76
	SRT-100	1	PX13
	SRT-101	1	PX13
	SRT-102	1	PX13
	SRT-200	1	PX13
	SRT-201	1	PX13
	SRT-202	1	PX13
	SRT-SC	1	PX13
	SRT-MC	1	PX13
	SR-7	1	PX13
	SR-7v	1	PX13
35mm Rangefinder Cameras			
	Hi Matic 7	1	PX13
	Hi Matic 7s	1	PX13
	Hi Matic 9	1	PX13
	Hi Matic 11	1	PX13
	Hi Matic E	2	RM640
	Hi Matic F	2	RM640
	Hi-Matic FP	2	RM640
	Hi Matic ES	2	RM640
	Hi Matic G	1	PX675
	Hi Matic C	1	PX675
	Hi Matic 5	1	PX675
126 Cartridge-loading Cameras			
	Autopak 500	2	MN2400
	Autopak 550	{2 1	PX825 PX625
	Autopak 800	{2 1	PX825 PX625
	Autopak 600-X	1	RM640
110 Cartridge-loading Cameras			
	Pocket 40	1	7R31
	Pocket 50	1	7R31
	Pocket 60	1	7R31
	Pocket 70	1	7R31
	Pocket 200	1	RM640
	Pocket 250	1	7R31
	Pocket 270	1	7R31
	110 SLR Zoom	2	MS76
Minolta 16 Cameras			
	16-MGS	1	PX675
	16-QT	1	PX30
MINOX			
	Minox "C"	1	PX27
	Minox BL	1	PX675
	Minox 35 EL	1	PX27
MIRANDA			
	Automex III	1	PX625
	Sensorex	1	PX625
	Sensomat	1	PX675
	Sensomat RE	1	PX675
	Sensorex II	1	PX675
	Auto Sensorex EE	1	PX675

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
MIRANDA (Continued)			
	Sensoret	2	RM640
	DX-3 Camera	4	MS76
NIKON			
	F Motor Drive (Battery Case)	8	MN1400
	F Photomic System	2	PX13
	Medical Nikkor Outfit (Battery Pack)	{1 4	PF491 and MN1300
	SP, 3-S Motor Drive (Battery)	6	MN1400
	Nikon F	2	PX13
	T Photomic System	2	PX13
	Photomatic F2	2	MS76
	Nikkormat FT, FTN	1	PX13
	Nikon F2 Motor Drive	10	MN1500
	F2, F2S Photomic	2	MS76
	F2 Motor Drive	10	MN1400
	Medical Nikor II	8	MN1300
	Nikkormat FTN	1	PX13
	Nikkormat EL	1	PX28
NORITA			
	66	1	MS76
OHSAWA SHOKAI			
	Harina C1-EE	2	MN2400
	Harina M1-EE	2	MN2400
	Harina S1-EE	2	MN2400
OLYMPUS			
	35SC	1	PX625
	Pen D2	1	PX625
	35EM	2	MN1500
	35LE	1	RM1R
	Pen D3	1	PX675
	35LC	1	PX625
	Pen FT	1	PX625
	EED	1	PX625
	Quick Matic EEM	2	MN1500
	35SP	1	PX625
	35EC	2	RM640
	35RC	1	PX625
	35EC-2	2	RM640
	35DC	1	PX625
	35 ECR	2	RM640
	FTL	1	PX625
	M-1	1	PX625
	OM-1	1	PX625
	35UC	1	PX625
J. C. PENNEY			
	X-200, X-300	1	PX30
	Pocket 333	2	MN1500
	SLR 2	1	PX13
	SLR 3	1	PX625
PERFECT PHOTO			
	I and II, 126 Cameras	8	MN2400
	Cube 602, 602B	4	MN1500
	Perma Matic 618	4	MN1500
PETRI			
	Flex 7	1	PX625
	Rapid	1	PX625
	Racer	1	PX625
	FT	1	PX625
	Anscomatic 726	1	PX625
	Anscomatic 626	2	MN2400
	Anscomatic 436	2	MN2400
	607	2	PX825
	Color	2	MN2400
	FTEE	1	PX675
	Color 35E	1	PX675
	FT II	1	PX675
	Computer 35	1	PX625
	FTE F 1.7	2	MS76

STILL CAMERAS (Continued)

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
PETRI (Continued)			
V6 II		1	PX625
M35		1	PX625
Color 35		{1 1	PX675 PX625
PETRI CINE			
Cinemax, Animatic		{1 2	PX13 and MN1500
POLAROID			
Land Electric Eye J-33		1	MN1500
Land Electric Eye J-66		1	MN1500
Land Electric Eye Model 850		1	PX13
Land Electric Eye Model 900		1	PX13
Land Automatic 100		{1 1	PX19 and PX21
Land Automatic 101, 102		{1 1 1	PX19 and MN1500 or PX21
Land Automatic 103, 104, 105		{1 1	PX24 and MN1500
Land Wink Light Model 250, 252		1	PX18 or PF460
200 Flash Gun		2	MN1400
201 Flash Gun		1	M215
202, 203, 221, 222, 240, 281 Guns		{1 1	M505 or M504
Land Model 20 "Swinger"		2	MN1500
Flash Gun 268		{1 1	PX21 or MN1500
220, 230, 240, 340		1	PX19
125, 135, 210, 215, 315,			
320, 325, 330		1	PX24
335, 350, 360		2	PX24
Big Swinger		2	MN1500
Color Pack II, III, IV		2	MN1500
280 Flash Gun		2	MN1500
Square Shooter, II		2	MN1500
Super Color Pack		2	MN1500
420, 430, 440		1	PX24
450		2	PX24
Count Down 70		1	PX24
Count Down 90		2	PX24
21P		2	MN1500
PRAKTI			
Prakti		2	MN1500
PRINZ			
Electro 126		1	PX28
REVERE			
No. 1054 Motorized Insta-Matic		2	MN1500
No. 1004 Insta-Matic		2	MN2400
1000, 1062, 1064		2	MN2400
1034, 1036, 1024		1	PX23
1074		{1 1	PX13 PX23
RICOH			
Super Shot		1	RM1R
520 M Cds		1	PX13
Singlex		1	PX13
Super Shot 2.4		1	PX13
35 Flex Cds		1	PX675
126 C EE		1	M504
126 C Flex TLS		{1 1	PX675 M504
126 C Deluxe		1	M504
126 C Automatic		1	M504
Hi Color 35		1	PX675
126 C Auto Cds		{1 1	PX675 M504
TLS 401		1	PX13
Auto Half SL		1	PX675
Elnica 35		2	RM640
500 G		1	PX675

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
RICOH (Continued)			
Flex TLS 401		1	PX625
Auto TLS-EE		1	PX625
500 GS		1	PX675
Hi Color 35S		1	PX675
ROLLEI			
Rollei 35M		1	PX13
Rolleiflex SL26, SL35		1	PX13
Rollei A26		1	PX625
A110		1	PX27
Rollei 35S			
Rolleiflex SL35, SL350,		1	PX625
Rollei XF35			
ROYAL			
RTL 1000, Pentagon 6TL		1	PX13
SIMPLEX			
41 Camera		2	MN2400
42 Thru 45 Cameras		2	MN1500
TARON			
Auto EE		1	PX625
Matic F		2	MN2400
Auto EL		1	PX625
Auto EL28		1	PX625
Electro 1000		1	PX28
Perma Matic 618		4	MN1500
TESSINA			
35L Flash Unit		1	M504
TOPCON			
Re Super		1	PX625
Uni		1	PX625
Re-2		1	PX625
Unirex		1	PX625
Unirex EE		1	PX625
1C-1 Auto		2	PX675
Super DM		1	PX625
U.S.C.			
Reflex III Color Kit		2	MN1500
No. 7501 Automatic 127 Kit		2	MN1500
Foldex "20" Kit		2	MN1500
VIVITAR			
450/SLD, 420/SL		1	PX675
250/SL, 220/SL, SLX 650, 406		1	PX28
602		2	MN1500
VOIGTLANDER			
VSL-1 35mm SLR		1	PX625
VSL-2 35mm Electronic SLR		4	MS76
VF101 35mm Electronic Rangefinder		4	PX625
WARDS			
Model X-42, 39		2	MN2400
Insta-Pak 204 and 126		2	PX825
Electric for CP302, RF450,			
S4R500, AM550, AM551,			
shr700, 850, 900		1	PX13
735, 736, 737		1	M504
YASHICA			
Penta J-3		1	PX625
Ministar D		1	PX625
Penta J-5		1	PX625
Lynx 5000		1	PX625
Ministar 700		1	PX625
Penta J-4		1	PX625
Lynx 14		1	PX625
Penta J-7		1	PX625
TL Super		1	MS76
Half 14		1	PX625
TL		1	MS76
Lynx 14E		1	RM640R

STILL CAMERAS (Continued)

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
YASHICA (Continued)			
	Mat 124	1	PX625
	EZ Matic Electronic	1	PX28
	Lynx 5000 E	1	RM640R
	TL-Electrox	1	PX28
	Electro 35 CC	1	PX28
	Electro 35 MC	1	PX28
	TL-Electro	2	RM640
	Electro AX	1	PX32
	Aoron Electro	1	PX28
	FFT	1	PX675
	TL Electrox	1	PX28
	Electro 35 FC	2	RM640
	Electro 35 GL	1	PX32
	Electro 35 CCN	1	PX28
	Electro 35 GSN, GTN	1	PX32
	Aoron Electro	1	PX28
	Electro 110S	{1 2	7R31 MN1500

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
ZEIS-IKON VOIGTLANDER			
	Vitessa 500 AE	2	PX625
	Contaflex 126	2	PX13
	Vitessa 500S	{1 1	PX13 or PX625

Movie Cameras

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
AGFA			
	Movex Automatic I & II	2	PX13
	Movex Reflex	3	MN1500
	Movex Zoom	2	MN1500
	Power Zoom Lens	2	PX1
	Movexoom	{1 5	PX13 and MN1500
	Movexoom 2000, 3000	6	MN1500
	Movex S, Movex SV	{1 4	PX13 and MN1500
	Microflex Sensor	{1 2	PX13 and MN1500
	Microflex 100, 200	{2 1	MN1500 PX13
ARGUS			
	Automatic 8	4	MN1500
	M-4 Power Zoom	4	MN1500
	M-44	{4 1	MN1500 and PX14
	Cinemax 85E 8mm	1	PX625
	Models 800, 801, 802, 806	4	MN1500
	Models 810, 812, 814, 820, 822	{4 1	MN1500 and PX13
	Auto-Zoom	2	MN1500
	Cosina 704, 706 Zoom	{4 1	MN1500 PX625
	Cosina 715, 718	{4 1	MN1500 PX14
	Models 803, 804	{4 1	MN1500 PX13
	Cosina	{4 1	MN1500 PX625
	Models 803, 804	{4 1	MN1500 PX13
	Models 815, 816, 820T, 822, 826	{4 2	MN1500 and PX13
	708	{4 1	MN1500 PX625
	715/718	{4 1	MN1500 PX14
	735/755	4	MN2400
	736/738/7310	{4 1	MN1500 PX14
	817/817E	4	MN1500
	818/818E	4	MN1500
	831XL/832XL	4	MN1500

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
BAUER			
	88G	1	PX1
	88-RS, Electric S	2	MN1500
	C-1, C-2, CZA, CZM	4	MN1500
	C2B	6	MN1500
	C1M, C2A, C2M, C20, 6X	4	MN1500
	Mini, Mini S	2	MN1500
	C2B and C Royal	6	MN1500
	C3, C21	3	MN1500
BELL & HOWELL			
	Models 416, 418, 426, 8315	1	PX1
	Models 434, 444	{4 1	MN1500 PX1
	Models 306, 311	1	PX14
	Models 430, 431, 8429, 8430, 8431, 8432	4	MN1500
	Model 432	{4 1	MN1500 PX14
	Models 440, 442, 443, 436, 8431S, 8432S	4	MN1500
	Models 372, 374, 375, 376, 379	4	MN2400
	Models 308, 339	{4 1	MN1500 PX13
	Model 240EE	2	PX14
	Models 491, 492, 493, 1201, 1204, 1206, 670, 671, 672, 674	4	MN2400
	Model 1208	3	MN1500
	Model 1216	4	MN1500
	1218, 673, 675	4	MN2400
	1230, 1235, 1236, 1238	6	MN1500
BOLEX			
	75, 150, 155, 160	{4 2	MN1500 PX13
	P4, K-1, S-1	1	PX1
	K2 Zoom	3	PX1
	Models 233, 233S, 350	2	MN1500
	Models 280, 250	5	MN1500
	Model P-3	2	PX1
	Models P-4, K-1	1	PX1
	Model K-2	3	PX1
	Model S-1	2	PX1
	Models 36EE, 86EE, 860EE	1	PX1
	Model 100 POE	3	PX1
	Angenieux 12-120 BDA	{4 2	PX1 or TR132

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
BRAUN-NIZO			
Nizo S80, S800		{6 2	MN1500 PX13
Nizo Elec. 4 & 8		1	PX13
Nizo 58E, 58L, 58T, S36		{4 1	MN1500 PX13
Nizo S40, S48, S55, S56, S560		{6 2	MN1500 PX13
S8E, S8L, S8T		{4 1	MN1500 PX13
S36		1	PX13
S30		4	MN1500
Nizo 800, 801, 561, 560, 481, 480		6	MN1500
Nizo 156XL		4	MN1500
Nizo Prof. 800P		6	MN1500
CAMERA SPECIALTY			
Cespeco, Kolnex, Mustang, Raynor, Starmax		{4 1	MN1500 PX13
CANON			
Motor Zoom 8 EEE		1	MN1500
Zoom 8-3		1	RM1R
Cine Canonet 8		{3 1	MN1500 PX1
Cine Zoom 512		1	PX1
Zoom 518 Super 8		{3 2	MN1500 PX625
Zoom 318 Super 8		{3 2	MN1500 PX625
Auto Zoom 814 Super 8		{4 2	MN1500 PX625
Single 8 518		{4 2	MN1500 PX625
Auto Zoom 518 Super 8		{4 2	MN1500 PX625
Auto Zoom 1218 Super 8		{5 2	MN1500 PX625
Zoom DS-8		8	MN1500
Cano Matic M70		2	MN2400
Auto Zoom 318 M		3	MN1500
Auto Zoom 814 E		4	MN1500
Auto Zoom 518 SV Super 8		4	MN1500
Single 8 518 SV		4	MN1500
512XL		4	MN1500
AZ 310XL		2	MN1500
AZ 514XL		2	MN1500
AZ 1014E		6	MN1500
CARENA			
Zoomex, Auto Carena		1	PX1
SLR, Zoomex S		2	PX625
COSINA			
Model 24		{4 2	MN1500 PX625
Model 5X, 8X		{6 2	MN1500 PX625
CHESTLINE			
CRS-1, CRS-11, Super 8		2	MN1500
DEJUR			
DC-533 Electra-Matic		2	MN1400
EFG20, 30, 40 & EF20, 30, 40		2	MN1400
Dejurette EF-10		{2 1	MN1500 and PX13
DE50, 60, 70, DEG55		{4 1	MN1400 and PX13
DEG65, Citation I and II, Electra V, VI, VIB		{4 1	MN1500 PX13
Electra VII, 250, 300, 400, 600, 650		{4 1	MN1500 and PX14
EHRENREICH			
Capro 100, 300, 400		4	MN1500
R-8, R-10		6	MN1400

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
ELMO			
8-R, 8-RS, 8-RT		4	MN1500
8-E		4	MN1500
8-EE		{1 1	MN1500 PX13
Pocket Auto		{4 1	MN1500 PX14
Zoom 8-C2		4	MN1500
Zoom 8-TL4, 4S, 6		4	MN1500
C-200, C-300		4	MN1500
Super 104		{4 1	MN1500 PX13
Super 106		{4 1	MN1500 PX13
Single 8 8S-40		1	MN1500
Super 103		2	MN1500
Super 103T		2	MN1500
Single 8 8S-30T		2	MN1500
Single 8 8S-30		2	MN1500
Super 204T		2	MN1500
Single 8 8S-40T		2	MN1500
Super 110		2	MN1500
EUMIG			
C5 & C6		5	MN1500
Eumigette Super 8		4	MN1500
308 Zoom Reflex		6	MN1500
C-10 Super 8		6	MN1500
S2 & Unilectric, S3 (Std. Format)		4	MN1500
Viennette (Super 8 Format)		6	MN1500
ELECTRA			
Zoomex		1	PX1
FUJICA			
Single 8 P1		{4 1	MN1500 PX14
Single 8 Z1		{4 1	MN1500 PX14
Single 8 Z2		{4 1	MN1500 PX14
Single 8 P300		{4 1	MN1500 PX14
Single 8 P100		{4 1	MN1500 PX14
Single 8 P105		{4 1	MN1500 PX14
Single 8 Z600		4	MN1500
Single 8 C100		{4 1	MN1500 PX13
ZX300			MN1500
Single 8 P400		4	MN1500
Single 8 Z400		{4 1	MN1500 PX14
Single 8 Z450		4	MN1500
Single 8 Z700		4	MN1500
Single 8 Z800		4	MN1500
Single 8 Pulse Think Corder		5	MN1500
Power Zoom Deluxe		{1 4	TR162R MN1500
GAF CORPORATION			
Titan I & II		4	MN1500
Titan III & IV		{4 1	{MN1500 (motor) PX13 (meter)
Anscomatic S/80, S/81, S/82, SC/90, SC/91		4	MN1500
SC/100, SC/102		{3 1	{MN1500 (motor) PX625 (meter)
Anscomatic S/62, S/84, S/85, S/86		{1 4	{PX13 (motor) MN1500 (meter)
Anscomatic S/75			
Anscomatic ST/84, ST/87, ST/88, ST/89, ST/90, ST/97, ST/99, ST/100, ST/101, ST/110, ST/111		{4 1	{MN1500 (motor) PX13 (meter)

MOVIE CAMERAS (Continued)

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
GAF CORPORATION (Continued)			
GAF64, 65, S/272		{2 1	{MN1500 (motor) PX625 (meter)
GAF S/72, 735, 738, S/70		4	MN1500
SC/92, S/83		{4 1	{MN1500 (motor) PX625 (meter)
Colt 84 (prior to 12/71), Colt 94		3	MN1500
Colt 84 (after 12/71), Colt 97, ST/202, ST/302		4	MN1500
GAF ST/99P, ST/101E, ST/104, ST/105, ST/111E, ST/400, ST/500, ST/600P, ST/600XI, ST/602, ST/800P, ST/801, ST/802		{4 1	{MN1500 (motor) PX14 (meter)
Compact 400		4	MN2400
GAF ST/1000, ST/1002		{4 1	{MN1500 (motor) PX625 (meter)
GAF XL110		{2 1	{MN1500 (motor) PX625
GAF XL112, XL120, XL125, SL128		4	MN1500
GAF 712, 713, 714, 415XL		4	MN1500
GAF SS250XL, SS505XL, SS605, SS805		{6 1	{MN1500 PX28
GAF XL Sound		{6 1	{MN1500 MN1604
Boom Condenser Microphone		1	MN1500
GAF-BERNARD			
Viceroy 201, 202		4	MN1500
Viceroy 203, CRS III, Viceroy 204, CRS IV		2 1	MN1500 (motor) PX14 (meter)
Viceroy 205, CRS V, Viceroy 206, CRS VI		2 1	MN1500 (motor) PX13 (meter)
Viceroy 207, 207PZ, 210, Viceroy 211, 212, 213, 255		4 1	MN1500 (motor) PX14 (meter)
Viceroy 200, 214, 250, 281, MSP4		4 1	MN1500 (motor) PX13 (meter)
Viceroy 208, 209		4 1	MN1500 (motor) PX29 (meter)
Viceroy 311		2 1	MN1500 (motor) PX625 (meter)
GAF-LENCO			
Lentar 2MZ, 3PZ		4	MN1500
Lentar Model 318		4	MN1500
Lentar 3X Model 693		4	MN1500
Lentar 4X Model 694		4	MN1500
Lentar 5X Model 694		4	MN1500
Lentar 5X Model 518		4	MN1500
Lentar 8X Model 817		4	MN1500
Focal 621, TLZ, TLZ II		{4 1	{MN1500 (motor) PX14 (meter)
Focal 500, 800, MZV, 900		{4 1	{MN1500 (motor) PX13 (meter)
HAIMEX			
XL25		2	MN1500
XL300		1	PX13
		4	MN1500
MXL311		1	PX13
		4	MN1500
MXL121		2	MN1500
HONEYWELL			
Elmo 8mm Cine Model 8-EE		4	MN1500
Elmo Dual-Filmatic		{4 1	{MN1500 PX25
Elmo Tri-Filmatic		{4 1	{MN1500 PX25
Elmo Zoom 83		8	MN1500
Zoom 81, 82		{8 1	{MN1500 and PX13
Pocket Auto 80		{4 1	{MN1500 PX13
Super 8 Filmatic, Tri-Filmatic		8	MN1500
Elmo Super 106 Super 8		{4 1	{MN1500 RM630

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
HONEYWELL (Continued)			
Elmo Zoom 81, 82, 83		{4 1	{MN1500 PX625
Elmo Super Filmatic 110		4	MN1500
Elmo Super Filmatic 103, 103T		2	MN1500
KALIMAR			
Compact 8		2	MN1500
K610, K611		{4 1	{MN1500 PX13
TV Zoom Reflex		4	MN1500
K683, K684, K686, 688		{4 1	{MN1500 PX14
KEYSTONE			
K609H, K610H, K616D, K614H, K615H		{4 1	{MN1500 PX625
K620, K622, K625		{4 1	{MN1500 PX640
K710H, K714HP, K715P, K716P		{4 1	{MN1500 PX14
810, 812, 813, 814		4	MN1500
820, 840, 860		3	MN1500
910XL, 920XL, 930XL		3	MN1500
XL100, XL200, XL300		3	MN1500
KOBENA			
121, 221, 321, 421		{4 1	{MN1500 PX13
KODAK			
Super 8 Models M-2, M-3, M-14, M-16, M-18, M-20		4	MN1500
Instamatic M-5, M-6		{1 3	{PX13 MN1500
Instamatic M-6 (Gray & Black)		{2 3	{PX13 MN1500
Instamatic M-4		{1 4	{PX13 MN1500
Instamatic M-8		{1 6	{PX13 MN1500
Hawkeye Instamatic		3	MN1500
Electric 8 Automatic, 8 Zoom		4	MN1500
Electric 8 Zoom Reflex		{1 4	{PX13 and MN1500
Instamatic M7, M9		{4 1	{MN1500 PX13
Instamatic M8		{3 1	{MN1500 PX13
Instamatic M22		2	MN1500
Instamatic M24, M26, M28, M30		{2 1	{MN1500 PX13
Instamatic Hawkeye Model B		2	MN1500
XL33		4	MN1500
XL55		4	MN1500
XL Models 320, 330, 340, 350, 360		4	MN1500
Ektasound 130, 140, 160		{6 1	{MN1500 MN1604
XL10		4	MN1500
Ektasound 150		{6 1	{MN1500 MN1604
KONICA			
Super-8 6TL		4	MN1500
Super-8 Compact 8		{2 1	{MN1500 PX13
KOPIL			
Zoom IIIA		1	PX1
LEITZ			
Leicina 8S, 8SV, 8V		{1 4	{PX13 or PX625 and MN1500
Leicina Super 8 & Model RT1		5	MN1500
Leicina Special		5	MN1500
Leicina Control Unit ST-1		5	MN1500

MOVIE CAMERAS (Continued)

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
MINOLTA			
Zoom 8		{4 1	MN1500 PX1
Auto Zoom 8		{4 1	MN1500 PX1
Minoltina		{4 1	MN1500 PX1
Auto Pack 8 K3		4	MN1500
Auto Pack 8 K5		4	MN1500
Auto Pack 8 K7		5	MN1500
Auto Pack 8 K11		5	MN1500
Auto Pack 8 S3		4	MN1500
Auto Pack 8 S6		4	MN1500
Auto Pack 8 D10, 8 D12		5	MN1500
Auto Pack D6		4	MN1500
Auto Pack D4		4	MN1500
XL250, 400		2	MN1500
Pocket Z-8		2	MN1500
Accessories for Movie Cameras			
Intervalometer P		5	MN1500
Intervalometer S		6	MN1500
Wireless Control Unit			
Receiver		{1 2	MN1604 MN1500
Transmitter		1	MN1604
NIKON			
Nikkorex 8, 8F		4	MN1500
Zoom 8		{4 1	MN1500 PX14
Bronica EC		1	PX28
F2, F2S Photomic		2	MS76
ETN, TN/T/F Photomic		2	PX13
Nikkormat EL		1	PX28
Nikkormat FTN/FT		1	PX13
Motor Drive MD-1, MD-2		10	MN1500
Motor Drive F36		8	MN1500
Motor Drive f36/f250		8	MN1400
Motor Drive SP		6	MN1400
Nikon R8		{6 2	MN1500 PX13
Nikon R10		6	MN1500
NIZO			
Electric, FA-3		1	PX13
Super		{1 4	PX13 and MN1500
OHSAWA SHOKAI			
Harina Matic Super 8		4	MN1500
Bell Howell Optronc Eye		4	MN1500
Bell Howell Forecastronic		4	MN1500
Bell Howell Auto Road 372		4	MN1500
Bell Howell Auto Road 374		4	MN1500
OLYMPUS			
Pen 8EE		4	MN1500
PATHE			
Duolight Electronic DS8 and 16MM		1	PX1B
J. C. PENNEY			
2-1 Manual Zoom		{2 1	MN1500 PX13
2-1 Power Zoom		{2 1	MN1500 PX13
4-1 Power Zoom		4	MN1500
6-1 Power Zoom		4	MN1500
8-1 Power Zoom		4	MN1500
XL160, XL250		3	MN1500
XL350, XL450		3	MN1500

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
PETRI			
Power Zoom 8		{1 4	PX1 and MN1500
8		4	MN1500
Flex 7		{1 1	PX13 or PX625
Rapid Load		1	PX13
PETRI-CINE			
MP-400, MP-500		{4 1	MN1500 and PX13
Cinemax 8H		{4 1	MN1500 PX13
Saimic ES25		{4 1	MN1500 PX13
Saimic Super 8		{4 1	MN1500 PX13
PONDER & BEST			
Vivitar 83, 84		4	MN1500
PRINZ			
BTL400, BTL600		{4 1	MN1500 PX14
BTL800 Zoom Arex		4	MN1500
Rexamat		{4 1	MN1500 PX13
RADIANT-PATHE			
DS8/BLT		1	PX1
REVERE			
Reflex Electric		{2 4	PX13 and MN1500
Super 8 S1		4	MN1500
RICOH			
Zoom Phonic		{4 1	MN1500 MN9100
Super 8 100F		{4 1	MN1500 PX13
Super 8 4002		{4 2	MN1500 PX13
Super 8 410Z		3	MN1500
Super 8 800Z		{4 1	MN1500 PX14
XL-250		4	MN1500
ROLLEI			
SL 81/82/85		3	MN1500
SL 83/84		6	MN1500
SL 86		2	MN1500
Rollei RM4-6-8		4	MN1500
RONDO			
Power Zoom		4	MN1500
ROYAL			
Cinemax NC400 & NC600		4	MN2400
Cinemax C802, 8X Marco Zoom		4	MN2400
Cinemax C1000, 10X Marco Zoom		4	MN2400
SANKYO			
CM-300		4	MN1500
CME-444, 666, 1100		4	MN1500
LXL-125, 145, 250, 255		4	MN1500
ES-33, 44		4	MN1500
ES-25XL, 44XL, 66XL		4	MN1500
XL-25S, 40S, 60S		6	MN1500
SEARS			
9110, 9116, 9117		{4 1	MN1500 PX625
9120, 9122, 9123, 9125		4	MN1500
9160, 9161, 9162		3	MN1500
9120, 9121, 9122, 9123, 9125, 9128 thru 9134, 9190, 9180		{2 1	MN1500 PX13
9136, 9166		{2 1	MN1500 PX14

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
SEKONIC			
	53EE & 53F3	1	PX640
	Duaimatic-50	{1 4	PX13 and MN1500
	Dual Run	1	PX1
	Zoom Model 100	1	PX640
URIU SEIKI			
	Cinemax Regular 8 85E	1	PX625
	Cinemax Super 8 C-501	1	TR112R
	Cinemax C-501	{4 1	MN1500 TR112R
	Cinemax C-801	{4 1	MN1500 TR113R
	Cinemax C-301	{4 1	MN1500 TR112R
	Cinemax NC-400	{4 1	MN1500 TR112R
	Cinemax NC-600	{4 1	MN1500 TR112R
	Cinemax C-802 Macro	{4 1	MN1500 TR113R
	Cinemax C-1000 Macro	{4 1	MN1500 TR113R
VERNON			
	8	4	MN1500
VIVITAR			
	TL3, TL4, TL6	4	MN1500
	TL268, TL368, TL468	{4 1	MN1500 PX13
	83, 84, 84P, 85P	4	MN1500
	94P, 98P, 98PM	4	MN1500
	100 PM	4	MN1500
WARDS			
	705	{4 1	MN1500 PX14
	7059, 706, 715	{4 1	MN1500 PX29
	7069	{4 2	MN1500 PX675
	716	{4 1	MN1500 PX675
YASHICA			
	8C, 7U-G, 8M, 8U	4	MN1500
	8U-P Power Zoom, 8UL, 8U5	{1 4	PX1 and MN1500
	8 U-matic	4	MN1500

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
YASHICA (Continued)			
	8 UL, 8 UP, 8 UC	{4 1	MN1500 and PX1
	Yashimat S	{1 4	PX1 and MN1500
	8 ES	4	MN1500
	U-Matic CdS	{4 1	MN1500 and PX1
	Yashimat Zoom	{4 1	MN1500 and PX1
	E-Zmatic Electronic	1	PX28
	Super 10, 25	4	MN1500
	Hobbyist S800	4	MN1500
	Super 825	4	MN1500
	Super 40N, Super 50N	{4 1	MN1500 and PX1
	Super 30, Super 50	{4 1	MN1500 PX1
	Super 30E, 40E, 60E, 600E, 800E, LD-4	4	MN1500
	LD-6, LD-8	6	MN1500
	Super 40K, YXL-1.1	{2 1	MN1500 PX13
	Macro-8	2	MN1500
	Yashica-12, 24	1	PX13
ZEISS-IKON			
	Movieflex Super	{2 1	MN1400 and PX1
	Zoomlex, Zoomphonic	2	MN1500
	Movieflex S8	4	MN1500

CdS Exposure Meters

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
ACCURA			
	CdS Clip-On	1	PX13
ARGUS			
	616	1	PX13
ASAHI-PENTAX			
	Spot Meter	1	PX640
	3/21 Meter	1	PX13
AUTOMEX			
	3	1	PX13
BESELER			
	BT-43 for EXAKTA MT Lens	2	MN1500
BEWI			
	Super	1	PX13

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
BOLEX			
	H, 36EE, 86EE	1	PX13
BOWER			
	CdS Meter	1	PX13
BRONICA			
	TLL Meter Model 1	2	MS76
	TTL Meter Model 2	1	PX28
CAMERA SPECIALTY			
	Capitol, Examat, Sedic, Toshiba, Travemat	1	PX13
CANON			
	Canon FP	1	PX13
	Canon Booster	3	PX13
	Booster T	1	PX28
	Servo EE Power Pack	8	MN1500

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
FOTOMATIC			
FC No. Z4 Meter		1	M215
Romeico Densitometer		{2	MN9100
		{2	MN1500
FC No. HSZ-5 Meter		2	MN9100
GAF-BERNARD			
Viceroy PR65, PR75		1	PX625
GOSSEN			
Luna-Six, Luna-Pro		2	PX13
Super Pilot, C-Mate		1	PX13
Ascor Flashmeter		1	MN1604
Panlux Electronic Footcandle Meter		1	MN1604
HANIMEX			
Meter for PRAKTICA 66		1	PX13
PR135, PR140		1	PX13
HONEYWELL			
Pentax Clip-On		1	PX13
Pentax Spot Meter		1	PX13
TTL Penta Prism		1	PX28
INTERPHOTO			
Sunset 65		1	PX625
JONAN ELECTRIC			
Elmat		1	MS76
Elite		1	MS76
Com		1	PX675
Lumitax 412		1	PX625
Lumitax 413		1	PX625
Vivitar SL		1	MS76
Vivitar 43		1	MS76 (PX675)
Pallas		1	MS76
Pallas Clip on		1	PX675
Stitz		1	PX625
Oray		1	PX625
Stitz M-4D		1	PX625
KALIMAR			
430		1	PX13
K429		1	PX13
K-437		1	PX13
K-438		1	PX13
K-431		1	PX13
K-433		1	PX13
KINOX			
Clip-on Model C-1		1	PX13
CdS Super Automat		1	PX640
KONICA			
CdS Meter for Konica FP		1	PX625
KOPIL			
Sekonic Micro Junior L-138		1	PX625
Sekonic Micro Reader L-98		1	PX625
Sekonic Micro Clip-on L-136		1	PX625
Sekonic Marine L-164		1	MN9100
Sekonic View Meter L-206		1	PX625
Sekonic Auto Range L-216		1	PX625
Sekonic Apex L-218		2	PX625
Sekonic Zoom Meter L-228		1	MN1604
KOWA			
Exposure Finder		1	PX625
LEICA			
Leicameter MR		1	PX13
LEITZ			
Leica Meter MR, Metrastar, MR4		1	PX625
MAMIYA			
RB Professional CdS Finder		2	MS76
C330, C220 Professional CdS Porro Finder		1	MS76

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
MINOLTA			
SR Meter II		1	PX625
SR Meter V		1	PX625
SR Meter S		1	PX625
Auto Code CdS		1	PX1
View Meter		1	PX1
Auto Spot 7 Degree		{1	MN1604
		{1	MN1500
Flash Meter		{5	PX625
		{1	MN1500
Flash Meter II		1	MN1604
Color Meter		5	PX625
Auto Meter Professional		1	PX28
MIRANDA			
Cadius		1	PX13
F Coupled Meter		1	PX13
FM 1		1	PX13
TTP, G		1	PX13
Clip on CdS Meter		1	PX625
TTL Pentarhythm CdS Meter		1	PX625
Pentarhythm Meter		1	PX625
NIKON			
Photomic Finder Model F		2	PX13
Photomic Finder Model T		2	PX13
Photomic TN, FTN		2	PX13
Photomic Illuminator		1	PX13
OLYMPUS			
Pen FV Meter		1	PX1
PETRI			
V6 CdS Meter		1	PX625
PETRI CINE			
Kine		1	PX13
POLAROID			
Model 628		1	PX13
RICOH			
Singlex Meter		1	PX625
Zoom Star Meter		1	PX625
ROLLEI			
Hood for Rolleiflex SL66		1	MN1604
SEARS			
8050		1	PX625
7312/22, 8890, 8875/85, and 9135		1	PX640
SEKONIC			
L-98 Micro-Leader Meter		1	PX13
L-136 Micro Meter		1	PX13
L-138 Micro Jr. Clip-On Meter		1	PX13
L-164 Marine Meter		1	PX13
L-206 CdS Meter		1	MN9100
L-216 & L-218 CdS Meters		1	PX13
L-256 Flash Meter		1	TR164
SOLIGOR			
Selector Meter		1	PX13
Sensor Cds Meter		1	PX14
Spot Sensor Meter		2	PX625
UF Meter		1	PX625
SPECTRA			
Combi — 500		2	PX625
SPOTRON			
Professional		{1	PX450, and
		{1	M505
SUNSET			
CdS 35 Exposure Meter		1	PX13

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
TOPCON			
	Meter Light	1	PX625
TOSHIBA			
	PE-1	1	PX13
	EE-101	2	MN1500
	EE-1100	1	MN1604
VICEROY			
	PR-65, PR-75	1	PX625
VIVITAR			
	Model 43, 24, 42	1	MS76
	Model 34	1	PX13
WESTON			
	Ranger 9	1	PX13
YASHICA			
	YEM-35, J-3	1	PX13

Make	Model	No. of Batteries	DURACELL® Replacement Batteries

Slide Viewers

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
ACCURA			
	2¼ x 2¼ Viewer	2	MN1400
AIREQUIPT			
	12X	2	MN1400
	No. 300	2	MN1500
	No. 400	2	MN1500
	Automatic	2	MN1400
	Chargermatic	2	MN1400
AREL			
	PM Deluxe	2	MN1400
ARGUS			
	Previewer I	2	MN1300
	Previewer III, IV	2	MN1500
	Electro-Matic 692	2	MN1400
BAIA			
	Ultra-Vue 1, Ultra-Vue Automatic	2	MN1400
	Model M200, M400, M800, M900 Auto	2	MN1400
BOWER			
	Cenei Cand C3 Scopers	2	MN1400
	Cenei Kt	4	MN1400
	Cenei K1 7x7 Scoper	4	MN1400
	Cenei K3 Stack Loader	4	MN1400
BRUMBERGER			
	1265 Stereo Viewer	2	MN1300
CENCI VIEWERS			
	C and C3 Scopers	2	MN1400
	KL Scopers	2	MN1400
	K3 Stock Loader	4	MN1400
GAF/SAWYER'S			
	Nomad Flash Attachment	2	MN1500
	GAF Zoom Viewer Ultra	2	MN1400
	GAF Zoom Viewer	2	MN1400
	Pana-Vue Zoom Deluxe	2	MN1400
	Pana-Vue Zoom Viewer	2	MN1400
	Pana-Vue Model I, 1 & 1R	2	MN1400
	Pana-Vue Model II & 2	2	MN1500
	Pana-Vue IV, 4 & 4R Viewer	2	MN1400
	Pana-Vue Bi-Lens Viewer	2	MN1400

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
GAF/SAWYER'S (Continued)			
	Pana-Vue Automatic, Automatic R & R	2	MN1300
	Pana-Vue Electric & Electric R Viewer	2	MN1400
	View-Master Focusing Viewer, Model D	2	MN1300
	View-Master Lighted Viewer, Models F & H	2	MN1400
	View-Master Light Attachment, Model E	2	MN1300
	View-Master Personal Flash Attachment	3	MN1500
	View-Master, Talking	2	MN1400
HANIMEX			
	Vista Viewer	4	MN1400
ITOREX			
	KB-110	2	MN1500
KALIMAR			
	K-3050, K-3015	2	MN1400
	K-3035, K-3045	2	MN1500
KARL HEITZ			
	Omag Viewer	2	MN1500
KENT			
	"BB," "A," Viscount 66	2	MN1400
KODAK			
	Illuminated Pocket Viewer	2	MN1500
LOGAN			
	Power Viewer	2	MN1400
MANSFIELD			
	202	2	MN1500
POLAROID			
	Model ZIP, 490	2	MN1500
REALIST			
	Regal Model	2	MN1400
	2061, 2062 Stereo	2	MN1400

	No. of Batteries	DURACELL® Replacement Batteries
Make	Model	

Flash Units

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
ALPEX (Continued)			
	Swivel	1	M215
	125, 605	1	M215
AMATEUR			
	111, 111L	3	MN1300
AMERICAN CAMERA			
	Minicam TT100	6	MN1300
	Minicam Twinklite 60, EF100	4	MN1300
	Minicam Twinklite P	6	MN1500
AMERICAN SPEEDLIGHT			
	A423	1	MN1300
AMGLO CORP.			
	PM 540, PMST 500	4	MN1300
	60-D1	1	PF492
	60-D2	1	PF497
ANSCO			
	JN 206	1	M215
	Lite Model I, II	1	M504
ARGUS			
	EM 3 & CB-3 Electr. Strobe	4	MN1500
	E2 & E3 Electr. Strobe	2	MN1500
	Flash for No. 127	2	MN1500
	Flash for 232 Auto. and A5	2	MN1500
	Gun (C4, C44, V100, EF, 21 Cameras, C3, Match-Matic C20), 758 (75 Cameras)	2	MN1400
	Model 232, 761	2	MN1500
	756 Folding Flash	1	M505
	758 Flash Unit	2	MN1400
	759 Folding Gun	1	M505
	760 Folding Flash	1	M505
	760 Folding Gun	1	M505
	761 Flash Unit	2	MN1500
	1250, 1264, 1240	2	MN1500
	1252/1254, 1275, 1271	4	MN1500
ASAHI PENTAX			
	Super Light	4	MN1500
ASCOR			
	A201, A202, A205	1	PF497
BALDESSA			
	Super Baldina	1	M215
	Vest Pocket, Five Shooter, Baldessamat F & RF	1	M504

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
BEACON			
	(All Camera Guns)	2	MN1500
BELL & HOWELL			
	B & H Infallible Unit	1	M504
BESELER			
	Beseler-Toshiba 440	2	M1500
	Topcon Flash Gun	1	M215
BOWENS			
	B-Flash Slave Unit	1	M504
	Multislave, M/S1 Flash Unit	1	M413
	Synchro Professional, 1/100 Multiflash Unit	1	M493
BOWER			
	AG1	1	M504
	Bounce Flash Gun	2	MN1500
	Duo-Lux X4 Cube—BC Shoe or Std. Pc.	1	PX23
	Electronic Flash	4	MN1500
	Folding Gun	1	M215
	Penlight	2	MN1500
	Perfec Tws. Ag-1 and XM1	1	M504
	Pocket Flash	2	MN1400
	Row I Illuminator	2	MN1400
	Row I No. 300 B-C Shoe and Std. Pc.	1	M504
	Schiansky R/C Cable Release	2	MN1500
	Sunblitz 3000	2	MN1500
BRAUN			
	F34, F16B, F16BLS	2	MN1500
	F40 Flash	6	MN1400
	RL510, RL515 Flash	1	PF497
	17B, BC	2	MN1500
	23B, BC, 28BC, BVC	4	MN1500
BRAUN HOBBY			
	Pocket Pac-F-30	6	MN1400
CAMERA SPECIALTY			
	Crony J3, J5	4	MN1500
	Praklina Camera Battery Pak	12	MN1300
CANON			
	Canolight D	2	MN1500
	Canolite ED	2	MN1500
	Canon Booster	2	PX625
	Flash Coupler L	2	PX625
	Flashcube Adapter	2	MN9100
	Models V, V-2, J	1	M505
	Models V-3, J-2, J-3, Quint, D	1	M504
	Speed Light 100	4	MN1500
	Speed Light 102	3	MN1500
	Speed Light 133D	4	MN1500
	Speed Light 200	4	MN1500
	Speed Light 500A	8	MN1500 or PF497
CAVALIER			
	Comptatron Flash Units	2	MN1500
	Power Beam # II Flash Units	2	MN1500
CLIBO			
	Gun	1	M215
DUO-LUX			
	Perfectus, Primus AG, Quick-Fire	1	M504
	Piccolo, Primus	1	M505
EHRENREICH			
	Capro FL3	2	MN1500
	Capro FL4, FL5, FL7	4	MN1500
EXAKTA			
	Edina, Edixa Guns	1	M215
	Standard Guns	1	M208
EXPERT			
	1B	4	MN1300
	11M	5	MN1300

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
FLASH FLEX			
	Flash Flex	1	M215
FOCAL			
	30 & Hini C	2	MN1500
FUJI			
	AG	1	M505
FUJICA			
	Fuji Color Strobo GP	4	MN1500
	Fuji Color Strobo GP-A	4	MN1500
	Fuji Color Strobo S	2	MN1500
GAF CORPORATION			
	Anscoflash I, II, III, IV, V, VII (Cadet II, III, GAF 127 Vagabond)	2	{ M15P M1500
	Anscoflash VI	1	M215
	Anscolite I (B-C Unit), II, IV	1	M504
	Anscomatic Cadet Flash 126, Cadet Flash, Anscolite III (Anscomatic Cadet)	2	MN2400
	JN206 Universal Flash	2	M14P
	with B-C Unit	1	M215
	Memolite Strobo	2	MN1500
	Pocket-Lite Strobo	2	MN1500
	X-Lite Strobo	2	MN1500
GAF-BERNARD			
	Viceroy Cube Flash Gun	1	M504
	Viceroy Strobo	6	MN1500
GAF-LENCO			
	DeLuxe Cube Gun	1	M504
	Goldcrest BC2, BC6, BC7, BC8, BC9 Guns	1	M504
	Goldcrest SR25, 28, 30, 33, 40, 42, Focal 40	4	MN1500
	Goldcrest SR35CD, SR45, SR50	4	NC13D
	Goldcrest SR101	2	MN1500
	Standard Cube Gun	1	M504
	Viceroy 708, 712, 8000	2	MN1500
GRAFLEX			
	Cartridges 2795, 2796, 8044, 8047, 8048, 8050, "Graflex 22"	1	M215
	Graflash PL (Ciro & Graphic 35)	2	MN1500
	Graflite Jr. 2850, 2851, 2852	2	MN1300
	Graflite 2725, 2727, 2735, 2737, 2738	2	MN1300
	Strobe 250	1	PF497
	Strobmite	4	MN1300
	Strobflash I	2	PF491
	Strobflash II, III, IV	2	PF489
HANIMEX			
	BX550	4	MN1500
	CBX350	4	MN1500
	CTX433	4	MN1500
	CTX435	4	MN1500
	CTX444	4	MN1500
	CX333	2	MN1500
	PFX33	2	MN1500
	TX60, 70	4	MN1500
	TX65, 3000	2	MN1500
	TX228	2	MN1500
	TX233	2	MN1500
	X333	2	MN1500
HARWOOD			
	Models I, II, IIIA	6	MN1300
HERSHEY			
	Sun-Ring "700"	4	MN1300
HEXETTE			
	Hexette	1	M505

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
HICO-LITE			
	109, 109 Pro-Deluxe, 228, 228 DeLuxe	2	PF491
HONEYWELL			
	Auto/Strobolite 57	2	MN1500
	Auto/Strobonar 890, 892	1	PF497
	Cartridges HR15, HR17	1	M215
	Foto-Mite	1	M505
	HR53 Fotoeye	1 or 2	M505
	55 Fotoeye	1	M505
	Strobolite 14, 18, 28	2	MN1500
	Strobolite 52, 55	2	MN1500
	Strobonar 100, 110, 109	2	MN1500
	Strobonar 810	1	PF497
	Tilt-A-Mite	1	M504
IKOBLITZ			
	C Flash Cube Holder	2	PX23
	III, Fold Fan	1	M215
	4, 4 Special, 5, 5 Special	1	M505
IMPERIAL			
	E-69	2	MN1500
	Permalite	2	MN1500
	400-FU	2	MN1500
INSTA-FLASH			
	126	2	MN2400
INTERPHOTO			
	Sunset Adapt-A Cube	1	M504
	Sunset No. 200X	1	M504
	Sunset No. 500 BC	1	M504
	Sunset TR100, NC200	4	MN2400
	1000 and 1500 B-C	1	M504
ITT			
	Magicflash EF202	2	MN1500
	Magicflash EF207	4	MN1500
JEN			
	BC Flash	1	M215
	Flash	3	MN1500
	Super Strobe DB, EC	2	PF492
	I, II	4	MN1300
KAKO			
	Auto-Beam, Auto-Beam II	4	MN1500
	Auto-Elite	4	MN1500
	Auto-Elite B, Elite L	4	MN1500
	Auto-F4M	6	MN1400
	Auto-30B	4	MN1500
	Auto-201	2	MN1500
	Auto 220	2	MN1500
	Auto-220S	3	MN1500
	Auto-224, 225	4	MN1500
	Auto-280, 460B, 250S	4	MN1500
	Auto-300S, 300B, 221, 822, 240B	4	MN1500
	Auto-918	2	MN1500
	Auto-928, 928B	4	MN1500
	Auto-3000	4	MN1500
	Kako 818, 818HS	2	MN1500
	Kakonet-P	2	MN1500
	Kakonet 4000, 4500, Auto 320B	4	MN1500
	Thyrostrobe 2000	4	MN1500
	Wide 220, 218	2	MN1500
KALIMAR			
	K450, K453, K455	1	M504
	K451	1	M505
	K452	2	MN1500
	K470, K460, K464, K472, K475	4	MN1500
	K471, K473, K412, K474, K476S, K450, K452	2	MN1500
	K-440, K-444	1	M504
	K-455, K-456, K-459	1	M504
	K-457, PM MAG5	1	M505
	K-464, Super 40	4	MN1500

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
KALIMAR (Continued)			
	K-470, K-472, K-475	4	MN1500
	K-471, K-473, K-412, K-418, K-414, K-415, K-462, K-476, K-474, K-476S, K-450, K-452	2	MN1500
	PM Mag-5	1	M505
	PM Mini Pack	4	MN1500
	PM Super-40, PM Mini-Pak K-460	4	MN1500
KARLART VICTOR			
	BC 400, MultiFlash	1	M215
	Master Speed Flash, Focuspot	3	MN1400
	Super Speed Flash, Deluxe, Compak	2	MN1400
KARL HEITZ			
	Flash Gun for Tessina 35		
	Subminiature	1	M504
KENT			
	AG-1 Penlite	2	MN1500
	AG-1 BC Flash	1	M504
	Mini-Mag, Multi-Mag	1	M504
	Mini-Mag, PM Multi-Mag, PM Auto-Cube and Hot Shoe		
	Model M-5, PM Mag-5	1	M505
KEystone			
	34, 44, 50, 60	2	MN1500
KLINE			
	Carea PFG 4, Six Shooter, Bounce Flash, Standard Flash	1	M215
KODAK			
	Brownie Fiesta	2	MN1500
	Brownie Reflex	2	MN1500
	C180 Flashcube Holder Model 1	2	PX825
	Ektamite Flashholder	2	MN9100
	Ektron, Model A & Model B	2	MN1500
	Electric Eye Remote Flash	3	MN2400
	Hawkeye Instamatic Flashholder	2	MN2400
	Kodablitz Flashholder	1	M504
	Kodalite Midget B-C Pak	1	M504
	Kodalite Midget Holder	2	MN1500
	Kodalite Super M40	2	MN1500
	Rotocube Flashholder	3	PX825
	Supermite Flashholder	2	MN1500
KONICA			
	BC Cubeflash	1	MN1504
	X-14	2	MN1500
	X14 Electronic Flash	2	MN1500
	X-20	4	MN1500
	X20 Electronic Flash	4	MN1500
KUBOLD			
	V, Lyon 11S	1	M215
LESTER DINE			
	Bright Speedlights	2	PF491
	"D" Pack	4	MN1300
	Light Light Deluxe	2	PF489
	Mighty Midget	2	PF492
	Swiftly I	2	PF492
LUX			
	Magazine Type I & II	1	M504
	Type I & II	1	M504
MATADOR			
	4805	2	PF491
MECABLITZ			
	100, 200	6	MN1300
	101	4	MN1300
	Megalume 3	{ 4	PF497 or MN1300
METZ			
	Medablitz 403	1	PF497

ELECTRONIC AND BULB TYPE FLASH UNITS (Continued)

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
MINICAN			
	Ring Flash	4	MN1300
	Speedlite 80 Flash Unit	4	MN1300
	Twinklite P, Flashgun	6	MN1500
	Twinklite 60 Flash Unit	4	MN1300
MINOLTA			
	Auto-Electroflash Model 22, 28, 32, 280	4	MN1500
	Auto/Electroflash Model 450	{6 1	MN1500 PF497
	Baby BC Flash	1	M505
	Deluxe II Flash, BCIII Flash, 16-G Flashgun, Flashcube Gun	1 2	M504 MN9100
	Deluxe III	1	M504
	Duofit S	1	M504
	Electroflash Model 1	4	MN1500
	Electroflash Model 2, S	4	MN1500
	Electroflash Model 3, CP, P	2	MN1500
	Electroflash Model 25B	2	MN1500
	16MG-S, Cube Gun	1	M504
	16MG-S, 16QT Cube Gun	1	M504
MINOX			
	BC, A, B, U, Cube Flash	1	M504
	B/C Flash	1	M504
	Cube Flasher	2	PX825
	Electronic	1	PF491
MULTIBLITZ			
	Color IIA, Press	2	MN1300
NATIONAL			
	Auto Pana PE-2800	4	MN1500
	Hi-per Flash Gun PB-3S	1	M504
	Hi-per Flash Gun PB-100	1	M215
	Hi-Pulse G PE-12	4	MN1500
	Mini Auto PE-2000	2	MN1500
	Mini Top PE-18	2	MN1500
	Mini Top II PE-201	4	MN1500
	Pana Magic PE-220	4	MN1500
	Pana Magic PE-240	4	MN1500
	Pana Photo Flash Gun PB-5	1	M215
	Pana Photo Flash Gun PB-5S	1	M215
	Pana Photo Flash Gun PB-6	1	M215
	Pana Shot PE-181	4	MN1500
	Professional PE-56	2	PF491
	Professional PE-562	2	PF491
NIKON			
	BC-3, BC-5, BC-2 Flash Attach.	1	M505
	BC-6, BC-1, BC-4 Flash Attach.	1	M504
	Field Illuminator	1	MN1500
	Flash Unit BC-5, BC-6	1	M505
	Flash Unit BC-7	1	M504
	Medical Nikkor I DC	4	MN1300
	Medical Nikkor II DC	8	MN1300
	Motor Drive	2	PF491
	Prof. Speed Light	12	MN1500
	Repeating Flash DC	3	PF497
	SB-1 W/D Cell Pack	6	MN1300
	SB-1 W/Hi-Volt Pack	1	PF497
	Speed Light	1	PF491
	Speed Light	6	MN1300
	Unity Pak	6	MN1300
OLYMPUS			
	Auto 300	4	MN1500
	Pen-Flash CL, II	1	M504
	PS 100 Flash Gun	2	MN1500
	II, CL	1	M504
J. C. PENNEY			
	Pocket Strobe	2	MN1500
PERFECT PHOTO			
	Perma-Cube	4	MN1500

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
PETRI			
	77	4	MN1500
PETRI CINE			
	Bounce Flash Gun	1	M215
	PFG3	2	MN1500
	PFG4	1	M215
	Rainbow Electric, Rainbow Jr.	4	MN1500
	Six Shooter	1	M215
POLAROID			
	200 Flashgun	2	MN1400
	201, 211 Flashgun	7	M215
	202, 222, 240, & 281 B-C Flashguns	1	M504
	268 Flash	1	MN1500
	280 Flashgun	2	MN2400
	490 Focused Flash	2	MN2400
PRAKTI			
	Guns	2	MN1500
	Praktiflex, Praktica, Pentacon Guns	1	M215
PRINZ			
	Emoluc BC	1	M504
	Rotomatic Cube	1	M504
	S1 and S2	2	MN1500
	Three-Way Bounce	1	M504
	Trilight Flash	4	MN1500
REALIST			
	Regal	2	MN1400
	ST525, Revere ST24	1	M215
	ST560, ST561, 1661	2	MN1500
REVERE			
	500, 504	2	MN2400
RICOH			
	B-605	1	M505
	Fanfold	1	M505
	Half Flash	1	M504
	Hi Strobo	{2 2	MN1500 MN1500
	Marine Flash	1	PX825
	Mini Flash	1	M504
	Pocket Flash	1	M504
	Right P	{2 2	MN1500 MN1500
	Sun Pak 100	2	MN1500
	Tron I	4	MN1500
	Tron II	4	MN1500
ROLLEI			
	B19BC	4	MN1500
	E15B	2	MN1500
	121BC	2	MN1500
	128BC	4	MN1500
	134B	4	MN1500
	134REB	4	MN1500
SAMIGON			
	2-28, 4-80 Electr. Flashgun	4	MN1500
SCHNEIDER			
	10527 Sun Lite 200 Flash	1	PF497
	10528, 10530, 10537, 10540	1	PF497
SEARS			
	8006 & 8008	4	MN1500
	8032 Folding Gun for 7868 and 7869	1	M504
	8901/08, 8030/32 Flashguns	1	M504
	8911/12 and 8001 Flashguns	4	MN1500
	80004	2	MN1500
SPEEDLIGHT			
	Mighty Light	2	MN1300
SPIRALITE			
	AC	2	MN1400

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
SPIRATONE			
	Ministrobe	2	MN1500
SUNLITE			
	11 Model 225	1	PF492
	11 Pocket-Pak, Model 240	{1	PF491 or
		4	MN1500
	100 B	1	PF497
	500, 600	1	PF491
	500, 700 Deluxe, "D" Units	4	MN1300
SUNPAK			
	Nocto 400, Auto 611		
	with Professional Powerpak	4	MN1500
	100, Auto 101	2	MN1500
	200, Auto 201, 300,		
	Auto 301, Auto 311,		
	Thyristor, 400, Auto		
	401, Auto 511	4	MN1500
SYLVANIA			
	Blitzgerät FA4	1	PX23
TICKY			
	CC, Min	4	MN1500
TIFFEN			
	Pocket Strobe #234	2	MN1500
TOPCON			
	Flash Gun	1	M215
TOSHIBA			
	AG Light	2	MN1500
	All Might Super II	1	M504
	Auto Flash	1	M504
	CL-1	1	M504
	Computer 724	4	MN1500
	Custom D II	2	MN1500
	Custom S II	4	MN1500
	Flash Ace FE-1	1	M504
	P-3 III	1	M215
	Pro Deluxe	1	M215
	Professional	2	PF491
	Rotomatic	1	M504
	318	2	MN1500
	328	4	MN1500
TULLY			
	Tully	1	M504
ULTIMA			
	Pocket Flash	2	MN1500
	40 & 40B	4	MN1500
ULTRABLITZ			
	Expert II, IV	5	MN1300
	Rocket	2	MN1400
	Rocket II, Mono Jet BL	2	MN1300
	Rocket D	1	PF497
ULTRA BLITZ/BAUER			
	E20AB	4	MN1500
	E200 and E201, E251, E252, E25A	1	PF497
	Ultrablitz Mates SP-6H	1	PF497
U.S. CAMERA			
	BP4	4	MN1300
	F4, F5	2	MN1400
	F10, F11, F12	1	M505
	F14, F15, F16, Trimatic 127,		
	Reflex 111	2	MN1500
U.S. PHOTO SUPPLY			
	Flashmaster, Microflash,		
	Microflash K-1	1	M504
VERNON			
	P-4, X-L	4	MN1500
	Swiva-Tilt	1	M504
	225	1	M505

Make	Model	No. of Batteries	DURACELL® Replacement Batteries
VISTA			
	Auto 30B & 46	4	MN1500
	28 & Auto 34	2	MN1500
	35C, Auto 34	2	MN1500
VIVITAR			
	Model 32	4	MN1500
	Model 32C	4	MN1500
	Model 44C	4	MN1500
	Model 50	1	7K67
	Model 90	4	MN1500
	Model 91	4	MN1500
	Model 100 New	1	MN1604
	Model 100 Old	4	MN1500
	Model 102	4	MN1500
	Model 110	4	MN1500
	Model 150	2	MN1500
	Model 151	2	MN1500
	Model 152	2	MN1500
	Model 200	1	MN1604
	Model 202	4	MN1500
	Model 251	2	MN1500
	Model 252	2	MN1500
	Model 272	2	MN1604
	Model 352	4	MN1500
VOIGTLANDER			
	VC38S, VC31S, VC21B	2	MN1500
WARDS			
	Folding Flash Gun	1	M504
	Meter for ep504, SLR600	1	PX1
	3200, 3201, 3203, 3204,		
	3205, 3206	1	PX1
YASHICA			
	Atoron-E Gun	1	PX13
	Atoron Flash Gun	1	PX13
	Auto ES-220	4	MN1500
	Flash Cube Adapter	1	M504
	Flash Gun II	1	M504
	Flash-O-Set II	1	M504
	Light AG-D	1	M504
	Lite	1	M504
	Mini Strobo	2	MN1500
	MS-20DX, MC-Lite	2	MN1500
	MS-110	2	MN1500
	Pro-40, 100	8	MN1500
	Pro-50	4	MN1500
	Pro-50DX	3	MN1500
	Super III Flash	1	M504
	Y-J Flash Gun	1	M505
	Y16 Flash	1	M505

DURACELL® Photo Battery Cross Reference Guide

Mallory Number	Voltage	Type	Eveready	Ray-O-Vac	Japanese
MN1300	D 1.5	Alkaline	E95	813	AM1
MN1400	C 1.5	Alkaline	E93	814	AM2
MN1500	AA 1.5	Alkaline	E91	815	AM3
MN1604	9.0	Alkaline	—	—	—
MN2400	AAA 1.5	Alkaline	E92	824	AM4
MN9100	N 1.5	Alkaline	E90	810	AM5
MS76	1.5	Silver	S76	RS76	GM13
PX1	1.35	Mercury	EPX1	RPX1	HS-P
PX13	1.35	Mercury	EPX13	RPX13	HS-D/H-D
PX14	2.7	Mercury	EPX14	RPX14	HS-2D/H-2D
PX19	4.5	Alkaline	531	RPX19	—
PX21	4.5	Alkaline	523	RPX21	—
PX23	5.6	Mercury	EPX23	RPX23	—
PX24	3.0	Alkaline	532	RPX24	—
PX25	4.05	Mercury	EPX25	RPX25	—
PX27	5.6	Mercury	—	RPX27	—
PX28	6.0	Silver	544	RPX28	4G13
PX30	3.0	Alkaline	EPX30	RPX30	—
PX32	5.6	Mercury	—	—	HM-4N
PX625	1.35	Mercury	EPX625	RPX625	H-D
PX640	1.35	Mercury	EPX640	—	H-N
PX675	1.35	Mercury	EPX675	RPX675	HS-C/H-C
PX825	1.5	Alkaline	EPX825	RPX825	AMF
RM400R	1.35	Mercury	E400	T400	—
RM640	1.4	Mercury	E640	T640	—
SA13D	D 1.5	Rechargeable Alkaline	—	—	—
SA14C	C 1.5	Rechargeable Alkaline	—	—	—
SA15AA	AA 1.5	Rechargeable Alkaline	—	—	—
TR112R	2.7	Mercury	—	—	KM-2D
TR164	5.6	Mercury	E164	T164	KM-4N
7R31	K 4.0	Mercury	538	RPX31	—
7K67	FLAT-PAK® 6.0	Alkaline	539BP	—	—
M215	22½	Zinc	412	215	O15
M504	15	Zinc	504	220	W10
M505	22½	Zinc	505	221	W15
PF489	225	Zinc	489	N150	—
PF491	240	Zinc	491	1010	O160
PF497	510	Zinc	497	1012	O320

DURACELL® Alkaline Photo Batteries



MN1300
D Size
1.5V



MN1400
C Size
1.5V



MN1500
AA Size
1.5V



MN1604
9V



MN2400
AAA Size
1.5V



MN9100
N Size
1.5V



PX19
4.5V



PX21
4.5V



PX24
3V



PX30
3V



PX825
1.5V



7K67
FLAT-PAK®
6V

DURACELL® Mercury Photo Batteries



PX1
1.35V



PX13
1.35V



PX14
2.7V



PX23
5.6V



PX25
4.05V



PX27
5.6V



PX32
5.6V



PX625
1.35V



PX640
1.35V



PX675
1.35V



RM400R
1.35V



RM640
1.4V



TR112R
2.7V



TR164
5.6V



7R31
K Size
4V

DURACELL® Silver Oxide Photo Batteries



PX28
6V



MS76
1.5V




M215
22 1/2 V



M504
15V



M505
22 1/2 V



PF497
510V

PF491
240V

PF489
225V

Zinc Carbon Photo Batteries



DURACELL PRODUCTS COMPANY

a division of P. R. MALLORY & CO. INC.
Berkshire Industrial Park, Bethel, Connecticut 06801