

Canon

CAMERA HOLDER



Canon Camera Co., Inc.

**Manufacturer & Exporter of
Canon Cameras & Serenar Lenses**




Set for vertical pictures

For taking sharp and well-composed pictures with your Canon camera, the use of a tripod and the Canon CAMERA HOLDER is highly recommended. With this HOLDER you can set your camera sturdily in perfect level—horizontally or vertically. Tripod sockets on the HOLDER are so located as to well-balance the camera mounted with SERENAR lenses of any focal length. Additional sockets can be used to mount Canon Side Lighting Units.

Images formed on 35 mm film will have to be reproduced either by enlargement on a photographic paper or by projection on a screen. Whichever it may be, it is extremely important to have the negatives sharply focused in perfect composition in

order to meet a great magnification and pleasant formation requirements. With the use of the Canon CAMERA HOLDER


these requirements can be easily accomplished whether it is close-up or distance shots at any shutter.



The Canon CAMERA HOLDER consists of a Cradle and a Bracket. The Cradle is of rigid and light weight aluminum die-cast with black Japanese lacquer finish and velvet lining for protecting the camera, while the Bracket is

made of brass with chromium plated finish. The built-in Spirit Level on the bracket affords a positive level for object composition.

HOW TO MOUNT THE CAMERA



Spirit Level

1. Mount the Bracket onto tripod.
2. Slide the camera into the Cradle.
3. Tighten the Safety Screw.
4. Place the Cradle onto the Bracket horizontally or vertically.
5. Tighten the Bracket Screw.

When necessary to interchange lenses or to reload film, dismount the camera from the Cradle by unscrewing the Safety Screw



Flash Unit Model X






Table Tripod



Flash Unit Model B-II

Extremely useful for taking perfectly composed sharp pictures especially for time or telephoto shots.

LISTINGS

Canon Camera Holder w/case

Canon Tripod

Canon Flash Unit, Model B-II w 'case

(for all Canons except Model IV)

Canon Flash Unit Model X

(for Canon Model IV)

1. *Main Flash Unit Housing w/Micro-Sync,
Battery Cap & Additional Batter3 Case*
2. *Side Lighting Unit Housing w/Clamp .*
3. *5" Reflector*
4. *7" Reflector*
5. *Penlight Battery Cartridge*
6. *Midget Bulb Adapter*
7. *Self-Extention Adapter*
8. *Extention Cord, 15 ft*
9. *Flash Tesfer*

*Items 1, 4, 5, 6, 7, 8, & 9 w/Leather
Carrying Case consititute a set*

Prices subject to change without notice.

Canon Camera Company, Inc.
Tokyo, Japan